

TIPS TO PLACE YOUR HEADLAMP STICKER


Only vehicles with the proper credential (headlamp sticker) can gain access to your community automatically and with ease through the resident entry lane. Please follow these important tips for placement of your headlamp sticker.

The vehicle headlamp sticker uses RFID technology similar to SunPass.

Headlamp stickers are non-transferable. Bending or attempting to remove your sticker from your vehicle will deactivate it.

PLACEMENT OF STICKER

- Clean the surface of the driver side headlamp where the sticker will be placed and allow to dry thoroughly. A 50/50 mixture of water/alcohol is best.
- Remove plastic protective film to expose the adhesive.
- **Position the sticker on the driver's side headlamp so it is front-facing and centered, with 2 inches of space between the sticker and any metal or edge, avoiding placement on any corners or curves (see image for recommended placement).**
- Place the adhesive side of the sticker onto the external mounting surface of the headlamp and press down firmly.



Contact your property manager for information on how to obtain your headlamp sticker.

CONSEJOS PARA COLOCAR LA ETIQUETA DEL FARO

Solo los vehículos con la credencial adecuada (etiqueta de los faros) pueden obtener acceso a su comunidad de manera automática y fácil a través del carril de entrada para residentes. Por favor, siga estos consejos importantes para la colocación de su etiqueta de los faros.


La etiqueta de los faros delanteros del vehículo usa tecnología RFID similar a SunPass.

.....

Las pegatinas de los faros son intransferibles. Doblar o intentar quitar su pegatina de su vehículo lo desactivará automáticamente.

COLOCACIÓN DE PEGATINA

- Limpie la superficie del faro del lado del conductor donde se colocará la pegatina y deje que se seque. Una mezcla de agua y alcohol 50/50 es lo mejor para usar para limpiar su faro.
- Retire la película protectora de plástico para exponer el adhesivo.
- Coloque la pegatina en el faro lateral del conductor de manera que quede orientada hacia el frente y centrada, con dos pulgadas de espacio entre la pegatina y cualquier metal o borde, evitando la colocación en esquinas o curvas (vea la imagen para la colocación recomendada).
- Coloque el lado adhesivo de la etiqueta adhesiva en la superficie de montaje externa del faro y presione firmemente hacia abajo.



Póngase en contacto con el administrador de su propiedad para obtener información sobre cómo obtener su etiqueta de los faros.